

Sink Faucet Installation Guide WAT-01-L



Installation:

1. Screw the supply lines into the faucet.

2. Thread the rods into the main faucet body.

3. Put supply lines through the sink hole and line up the rubber gasket.

4. Position bottom gasket.

5. Slide bottom washer through the rods.

6. Screw nuts onto the rods using the supplied tool.

7. Connect the supply lines to the water main.

